## Service 235 - CUTTING



Cutting

item	Order No.
hose cut along the spiral	235-0000-0000
vertical hose cut	235-0000-0800
cutting, insulation remove, turn wire into hose	235-0000-0900
leading-out wire out of the sprue	235-0000-0901
wire bending (without insulation remove)	235-0000-0902

Positive and negative pressure ratings are the recommended maximum operating values. Products can be manufactured to meet higher operating values upon request. The bend radius is calculated from the center of the hose in an arched position. Additional information at <u>www.norres.com/us/technology/</u>. NORRES reserves the right to modify technical data at any time. Technical data based on tests at 68°F and are approx. values. Proper use and maintenance of NORRES hoses is the sole responsibility of purchaser and ultimatewer of hear control of the hose in an arched positions and the number of variables make firm recommendations technically impossible. This information is intended as a general guide only.